

Taking care of your guitar

- Always keep your instrument in the case when not in use.
- Avoid extreme temperatures, leaving the instrument next to a radiator or in a cold damp room, or in direct sunlight in a car and so on.
- Clean your instrument after use with a DRY micro fibre/ lint free cloth.
- Always wipe down the strings after use. They will last longer.
- Change your strings once they become non responsive and your tone loses brightness. On a frequently used steel string guitar (electric/ acoustic), you may need to change strings once a month.
- You need to take your instrument to a professional if you have any of the following problems: Fret buzz, incorrect intonation, warped fingerboard, incorrectly adjusted truss rod, uneven string heights, any electrical problems with tone or volume pots (electric guitars only).
- If you have a very good instrument that is being used frequently, it is advisable to bring it to a professional once a year to 18 months for a professional clean and service.